

# Manometer Instructions

- remove tube from manometer
- insert one end past trap in drain or toilet
- fill manometer with water to "0"
- blow into flex tube already in toilet and check for blow back
- if there is blow back, blow again, pinch tube and reconnect to manometer
- the back pressure should raise the reading on manometer to 1,2 or 3
- wait overnight and check that the back pressure is the same the next day. This proves there are no leaks in drain system
- **ALL DRAINS AND AIR VENTS MUST BE SEALED BEFORE STARTING THIS PROCEDURE**