

# Moonwalk

## Preparation

Inspect the potential set-up area for being level, free of sharp objects, and enough room to allow at least 5 feet of free area on each side of the unit. Make sure to check the overhead clearance to be free of trees, wires, etc. The unit height is 15 feet. The set-up area should be on high ground and away from standing water. A grass surface is preferred. If on concrete or asphalt, lay a tarp down on the surface prior to putting the moonwalk on it to prevent damage to the bottom of the unit.

## Set Up

Locate a 110V outlet on at least a 20 amp circuit within 50 feet of the unit. A 50 foot extension cord is the maximum length allowed to prevent the blower from burning out. No credits will be issued if extension cords longer than 50 feet are used. It is the customer's responsibility to furnish an adequate outlet for the motor.

## Anchoring the Unit

Before anyone can jump on the unit, the unit should be anchored. The stakes should be driven into the ground as deep as possible on a slight angle for a good hold and to minimize tripping on all four corners.

## Once the Unit is inflated

Inspect for proper air pressure. If the unit feels too soft, do the following:

The moonwalk is equipped with 2 "necks" in the rear. One "neck" should have the blower connected to it. The other "neck" should be tied off. Check to assure both "necks" are securely attached and tied off.

Make sure the "neck" with the blower attached to it is as straight as possible. The straighter the "neck", the more air is being provided to the inflation of the moonwalk.

If this does not work and it is still too soft, inspect the unit to see if there are any holes or areas where there is an extensive amount of air loss. Keep in mind that the moonwalk is stitched together, so there will be some air loss from the stitches.

When not in use, deflate the moonwalk. To reuse the moonwalk, just plug the motor back in to inflate.

## Safety Rules

- A responsible adult is required in attendance and posted at the door at all times.
- Maximum number of jumpers is 8 under the age of 8 or 5 adults.
- No shoes allowed inside the moonwalk.
- No flips, wrestling, or other forms of "rough housing" allowed while inside the unit.
- Do not bounce closer than 4 feet from each other.
- Do not bounce near the doorway.
- No climbing or hanging on the outside roof or wall.
- No one is allowed inside while it is being inflated or deflated.
- Do not erect in high winds.

- Do not use if it's raining or wet.

**Customer accepts responsibility for all liability issues!**

**Takedown Instructions**

Make sure everyone is out of the unit. Remove all foreign objects; including dirt, grass, etc. Shut off blower. Remove and untie the deflation tube. Remove the stakes.

**Folding up the Moonwalk**

- Stand in front where the doorway is. Fold down all columns, sides, and necks into the base area.
- Fold the right side into the center line of the base area. Do exactly the same with the left side. The right side and left side will touch in the center of the base area.
- Fold the left side over the right side.
- Fold the front 1/3 of the distance towards the back, working out the trapped air.
- Start rolling the unit towards the back working out any additional trapped air.
- Attach the tie straps and tie around the unit.
- Do not lift the moonwalk alone, this could cause serious injury.

**A to Z Rental Center  
Eden Prairie Rentals  
12450 Plaza Drive  
Eden Prairie, MN 55344  
PH:(952)944-6916**